

Top Clean: Install Instructions (without sub base)

1. For best results remove the existing surface. Leave a 1 - 2% slope for drainage. This can be done by machine or manually depending on area



2. Break up approx 5cm of the surface with a strong rake or similar tool. This allows the mat to imprint and fit into the ground.



3. Lay the mats in a masonry configuration with a 1 - 2 cm gap between each mat. Cut the mats with a manual or powered saw.



Top Clean: Install Instructions (without sub base)

4. Spread sand onto the mats starting from one area and working outwards. Approx 15 kg per mat for a level covering.



Areas to use Top Clean: feeding areas, slopes, open paddocks, track systems

