

Top Clean Installation Instructions (Without Sub Base)



1. For best results, remove the existing surface leaving a 1-2% slope for drainage. This can be done manually or by machine. More effort with prep work to level the ground will result in a much smoother surface as the Top Clean mats will otherwise follow the ground undulations



2. Break up approx 2cm of the top surface with a strong rake or similar tool. This is very important to allow the entire underside of the mat to imprint and "grip" the ground. Top Clean should not be installed over deep dry ruts.



3. Lay the mats in a masonry configuration with a 1-2cm gap between each mat. Cut the mats to fit with a manual or powered saw if necessary. Gaps allow for drainage and a small amount of expansion.



Top Clean Installation Instructions (Without Sub Base)



4. Spread sand onto the mats starting from one corner and working outwards. 1 mat requires approx 15 kg for a level covering. Sand will increase the stability of the Top Clean mats.



Areas to use Top Clean:

Feeding areas, slopes, open paddocks, track systems, gateways, turnout pens



Jelka is not responsible for damage caused to the Top Clean mats by incorrect installation.

Please take great care when handling the mats, wear appropriate footwear/gloves and take consideration for the weight of the mats (29kg each), for example 2 person lift per mat.



Sand is an optional surface covering. We recommend sand as it is intended to increase surface slip resistance and aid poo picking. Sand is not intended to be used inside feeding stations due to the risk of sand ingestion by the horses.